Programming a Personal Entry Code (if desired)

NOTE: If you lose your code card, please contact your Ford/Lincoln dealership for factory code retrieval.

NOTE: Do not set a personal code that uses five of the same number. Do not set a personal code that uses five numbers in sequential order. There is a maximum of two access codes; the factory set code and one personal code. If you reprogram the personal code the prior personal code will be erased.

Enter the factory set code, as indicated on your Code Card. Within five seconds of entering the factory code, press and hold the 1/2 button for 1 second, the 9/0 button will flash twice to confirm the keypad is in programming mode.

Within five seconds, enter your desired personal 5-digit code. Each digit must be entered within five seconds of the previous digit.

The vehicle doors will unlock-lock-unlock to confirm that your personal code has been programmed to the keypad and the 9/0 button will flash twice to confirm that the keypad has exited programming mode.

To Remove a Personal Code, (if desired)

Enter the factory code, then within five seconds press and hold the 1/2 buttons, for 5 seconds. The vehicle will unlock, lock and then unlock to confirm that your personal code has been removed. The 9/0 key will flash four times (2 quick then 2 slow) to confirm that your personal code has been removed. Release the 1/2 button.

Owner's Instructions

Using the Keypad

NOTE: Refer to the "Locks and Security" section of your vehicle Owner's Guide for operation of remote transmitters during RUN/START. Remote transmitter operation in RUN/START key position is model dependent.

To unlock the driver's door, enter your personal 5-digit code or the factory set code. Each digit must be pressed within five seconds of each other.

To unlock all doors, press ¾ button within five seconds of entering a valid keypad code.

To lock all doors, press the 78 and the 9/0 keys simultaneously. You do not have to enter a 5-digit code.

To unlock the trunk or hatch, if equipped, press the 5/6 button within five seconds of entering a valid keypad code. (Integrated Keyfob Transmitter vehicles may require the 5/6 button to be pressed twice).

Anti-Scan Mode

If the wrong code has been entered 7 times (35 consecutive button presses) the keypad is disabled for one minute and the keypad lights will flash during this time.

Low Power Warning

If you unlock the door with the keypad and the locks cycle one additional time, it is time to replace the unit. The battery is not replaceable.

Place this card with the vehicles owner's manual.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.